

Recommended Wall Backing

Vertical Backing for 20" wide Rails

Locate and mark centerline on the mounting wall. Measure and mark 8½" on both sides of centerline. These two marks, 17" apart, represent the centerline of your vertical backing. Install 2x6's centered on each mark with the 6" side facing into the shaft and running vertically up the entire shaft.

